

TECHNOTE

[33/2014]


DATE: November, 2014
AUTHOR: cardPresso TECHNICAL SUPPORT
PRODUCT/AREA: Print

Subject: Overlay with Datacard XPS driver


To customize an Overlay design for a Datacard printer with XPS driver please do the following:

Select your printer in the drop down box under cardPresso's menu **File -> Print Settings**.

Under **Print Options**, on the right side of the menu window, the settings for Overlay Mode and File location should automatically be filled as seen in the print screen below:



Use the **Advanced Options** button to access your printer driver and configure it as shown in the print screen below:



Create your overlay design using the **Overlay/Varnish** tab at the bottom of the screen.

Always return to the **Design** tab, so that you are viewing your Layout design instead of your Overlay design, before printing.